

OPT PAG

0000 WAVBAS EQU \$0000
0008 WAVXB EQU \$0008
000C WAVXC EQU \$000C
0010 WAV10 EQU \$0010
0014 WAV14 EQU \$0014
01FF WX1FF EQU \$01FF
07D0 WX7D0 EQU \$07D0
0800 WX800 EQU \$0800
08BF WX8BF EQU \$08BF
1000 W1000 EQU \$1000
1034 W1034 EQU \$1034
1400 W1400 EQU \$1400
2C00 W2C00 EQU \$2C00
3000 W3000 EQU \$3000
3C01 W3C01 EQU \$3C01
4000 TENDE EQU \$4000
5800 WASS1 EQU \$5800
580A WASS2 EQU \$580A

6003 TAXA1 EQU \$6003
7F00 TAXA2 EQU \$7F00
C080 LBUFR EQU \$C080
CC14 LPTER EQU \$CC14
CC20 D0SER EQU \$CC20
CD00 FLEX EQU \$CD00
CD4B DOCMND EQU \$CD4B
D403 FMSCLS EQU \$D403
DF00 DRIVER EQU \$DF00
E000 ZE000 EQU \$E000
E900 ZE900 EQU \$E900
*RAMANF EQU \$EA10

EB10 STOR3 EQU \$EB10

EE04 STOR4 EQU \$EE04
EE05 SOFKEY EQU \$EE05
EE09 STOR5 EQU \$EE09
EF00 STOR6 EQU \$EF00
EF04 STOR7 EQU \$EF04
EF05 XKOR EQU \$EF05
EF07 YKOR EQU \$EF07
EF0E INVFLB EQU \$EF0E
F018 OUTCH EQU \$F018
F027 PDATA1 EQU \$F027
FCF0 KEYB0 EQU \$FCF0
FCF1 KEYB1 EQU \$FCF1
FCFA PIAA EQU \$FCFA
FD00 PIA EQU \$FD00

*PIA+1 EQU \$FD01
*PIA+2 EQU \$FD02
FF05 INVSF EQU \$FF05

V.CMD

V2 R3.3

5.OCT 1984

Waveterm

} Keyboard (Tastatur extn)
SoftKey FCF.A, B
Bus PPG

FCF4 CONTROL
FCF5 ACIA
Data

PIA FCF8
FCF9 PPG Wandler
FCFA

272	581E 5AAC	FDB	OUTHUN	
273	5820 587D	FDB	INCHA	
274	5822 5804	FDB	SETOUT	
275	5824 5AE7	FDB	SECUR	
276	5826 59B0	FDB	INPOS1	
277	5828 5D8F	FDB	TEXAE	<i>Sende Nr. 2</i>
278	582A 584A	FDB	TASHEL	
279	582C 5913	FDB	EINGAB	
280	582E 5CEF	FDB	KEYOUT	
281	5830 5984	FDB	INVCH	
282	5832 5871	FDB	OUTCX	
283	5834 5DE6	FDB	SENDE	<i>Sende Nr. 1</i>
284	5836 5900	FDB	INBUF	
285	5838 5908	FDB	INB2	
286	583A 58E9	FDB	DOS	
287	583C 5D9C	FDB	SENTST	

288

289

290

* *****

291	583E 86 01	START	LDA	##01
292	5840 87 EE04		STA	>STOR4
293	5843 8E 5BD1		LDX	##SOFT1
294	5846 8F EE05		STX	>SOFKEY
295	5849 86 EE07		LDA	>STOR5
296	584C 81 55		CMPA	##55
297	584E 27 1A		BEQ	GETTCMD
298	5850 86 55		LDA	##55
299	5852 87 EE07		STA	>STOR5
300	5855 7F EB0C		CLR	>STOR1
301	5858 8E 0000		LDX	##WAVBAS
302	585B 86 80		LDA	##80
303	585D A7 80	LOOP1	STA	,X+
304	585F 8C 4000		CMPX	##TENDE
305	5862 26 F9		BNE	LOOP1
306	5864 8E 5870		LDX	##XGETX
307	5867 8D 5D4A		JSR	>STORE
308	586A 8E 5878	GETTCMD	LDX	##XTCMD
309	586D 7E 5D4A		JMP	>STORE

310

311

312

* *****

313	5870 47 45 54 20	XGETX	FCC	"GET 0,X"
	5874 30 2E 58			
314	5877 04		FCB	##04
315				
316	5878 54	XTCMD	FCC	"T"
317	5879 04		FCB	##04
318				
319	587A 10CE EF00	INITAS	LDS	##STOR6
320	587E 86 01		LDA	##01
321	5880 87 EF0E		STA	>INVFLG
322	5883 7F EA36		CLR	>ECHO
323	5886 7F EA48		CLR	>ZIFF
324	5889 8D 587D		JSR	>INCHA

379	58F5	BD	D403		JSR	>FMSCLS
380	58F8	7F	CC20		CLR	>DOSER
381	58FB	35	04		PULS	B
382	58FD	1A	10	DOS1	ORCC	##10
383	58FF	39			RTS	
384						
385	5900	108E	C080	INBUF	LDY	#LBUFR
386	5904	10BF	CC14		STY	>LPTER
387	5908	A6	80	INB2	LDA	,X+
388	590A	81	04		CMPA	##04
389	590C	27	04		BEQ	INB1
390	590E	A7	A0		STA	,Y+
391	5910	20	F6		BRA	INB2
392						
393	5912	39		INB1	RTS	
394						
395	5913	5F		EINGAB	CLRB	
396	5914	7F	EB04		CLR	>INPENS
397	5917	86	09		LDA	##09
398	5919	BD	5A43		JSR	>INDEZO
399	591C	81	FF		CMPA	##FF
400	591E	26	01		BNE	NEUINI
401	5920	39			RTS	
402						
403	5921	4D		NEUINI	TSTA	
404	5922	1027	FF18		LBEQ	START
405	5926	81	09		CMPA	##09
406	5928	27	34		BEQ	DELET
407	592A	81	05		CMPA	##05
408	592C	22	29		BHI	ININEU
409	592E	27	3A		BEQ	ININE1
410	5930	7D	EB00		TST	>FILE
411	5933	27	0F		BEQ	VERSAZ
412	5935	8E	59A0		LDX	#GETRX
413	5938	8D	43		BSR	HDLFIL
414	593A	34	12		PSHS	X,A
415	593C	BD	6003		JSR	>TAXA1
416	593F	35	12		PULS	X,A
417	5941	7F	EB00		CLR	>FILE
418	5944	B7	EA3D	VERSAZ	STA	>PAGES
419	5947	8E	5800		LDX	##WASS1
420	594A	4A			DECA	
421	594B	48			ASLA	
422	594C	AE	86		LDX	A,X
423	594E	8C	0000		CMPL	##WAVBAS
424	5951	27	04		BEQ	ININEU
425	5953	32	63		LEAS	#03,S
426	5955	6E	84		JMP	,X
427						
428	5957	5F		ININEU	CLRB	
429	5958	BD	5A43		JSR	>INDEZO
430	>595B	16	FFC3		LBRA	NEUINI
431						
432	595E	8E	5D7C	DELET	LDX	#DCMDX

480	>59D6	BD	59C4		JSR	>INDZC
481	59D9	81	FF		CMPA	##FF
482	59DB	26	06		BNE	INDE2
483	>59DD	BD	5984		JSR	>INVCH
484	59E0	32	62		LEAS	#02,S
485	59E2	39			RTS	
486						
487	59E3	E6	07	INDE2	LDB	#07,X
488	59E5	C5	04		BITB	##04
489	59E7	27	0C		BEQ	INDE4
490	59E9	81	09		CMPA	##09
491	59EB	27	04		BEQ	INDE3
492	59ED	81	63		CMPA	##63
493	59EF	26	04		BNE	INDE4
494	59F1	86	FF	INDE3	LDA	##FF
495	59F3	20	0C		BRA	INDE6
496						
497	59F5	A1	04	INDE4	CMPA	#04,X
498	59F7	24	02		BCC	LOOP4
499	59F9	A6	04		LDA	#04,X
500	59FB	A1	05	LOOP4	CMPA	#05,X
501	59FD	23	02		BLS	INDE6
502	59FF	A6	05		LDA	#05,X
503	5A01	A7	98 02	INDE6	STA	[#02,X]
504	5A04	34	02		PSHS	A
505	5A06	BD	5984		JSR	>INVCH
506	5A09	A6	07		LDA	#07,X
507	5A0B	85	01		BITA	##01
508	5A0D	26	03		BNE	LOOP5
509	>5A0F	BD	5A14		JSR	>INVER5
510	5A12	35	82	LOOP5	PULS	PC,A
511						
512	5A14	B6	EF0E	INVER5	LDA	>INVFLG
513	5A17	34	02		PSHS	A
514	5A19	7C	EF0E		INC	>INVFLG
515	5A1C	EC	84		LDD	,X
516	5A1E	BD	5AE7		JSR	>SECUR
517	5A21	E6	98 02		LDB	[#02,X]
518	5A24	A6	07		LDA	#07,X
519	5A26	85	04		BITA	##04
520	5A28	27	10		BEQ	INDE9
521	5A2A	C1	FF		CMPB	##FF
522	5A2C	26	0C		BNE	INDE9
523	5A2E	86	58		LDA	##58
524	5A30	BD	5B71		JSR	>OUTCX
525	5A33	86	20		LDA	##20
526	5A35	BD	5B71		JSR	>OUTCX
527	5A38	20	03		BRA	LOOP6
528						
529	>5A3A	BD	5ABC	INDE9	JSR	>OUTDEZ
530	5A3D	35	02	LOOP6	PULS	A
531	5A3F	B7	EF0E		STA	>INVFLG
532	5A42	39			RTS	
533						

534	5A43	7C	EA48	INDEZO	INC	>ZIFF
535	5A46	5D			TSTB	
536	5A47	27	39		BEQ	IND2
537	5A49	86	EB01		LDA	>INPW
538	5A4C	81	FF		CMPA	##FF
539	5A4E	27	16		BEQ	IND4
540	5A50	7F	EF0E		CLR	>INVFLG
541	5A53	7C	EA36		INC	>ECHO
542	5A56	34	02		PSHS	A
543	5A58	8B	30		ADDA	##30
544	5A5A	BD	5B71		JSR	>OUTCX
545	5A5D	35	02		PULS	A
546	5A5F	C6	FF		LDB	##FF
547	5A61	F7	EB01		STB	>INPW
548	5A64	20	07		BRA	IND6
549						
550	5A66	BD	5B7D	IND4	JSR	>INCHA
551	5A69	81	FF		CMPA	##FF
552	5A6B	27	35		BEQ	IND9
553	5A6D	4C		IND6	INCA	
554	5A6E	C6	F6		LDB	##F6
555	5A70	CB	0A	LOOP7	ADDB	##0A
556	5A72	4A			DECA	
557	5A73	26	FB		BNE	LOOP7
558	5A75	BD	5B7D		JSR	>INCHA
559	5A78	81	FF		CMPA	##FF
560	5A7A	27	26		BEQ	IND9
561	5A7C	34	04		PSHS	B
562	5A7E	AB	E0		ADDA	,B+
563	5A80	20	20		BRA	IND9
564						
565	5A82	B6	EB01	IND2	LDA	>INPW
566	5A85	81	FF		CMPA	##FF
567	5A87	27	16		BEQ	IND3
568	5A89	7F	EF0E		CLR	>INVFLG
569	5A8C	7C	EA36		INC	>ECHO
570	5A8F	34	02		PSHS	A
571	5A91	8B	30		ADDA	##30
572	5A93	BD	5B71		JSR	>OUTCX
573	5A96	35	02		PULS	A
574	5A98	C6	FF		LDB	##FF
575	5A9A	F7	EB01		STB	>INPW
576	5A9D	20	03		BRA	IND9
577						
578	5A9F	BD	5B7D	IND3	JSR	>INCHA
579	5AA2	7F	EA48	IND9	CLR	>ZIFF
580	5AA5	7F	EA36		CLR	>ECHO
581	5AA8	7C	EF0E		INC	>INVFLG
582	5AAB	39			RTS	
583						
584	5AAC	86	20	OUTHUN	LDA	##20
585	5AAE	C1	64		CMPS	##64
586	5AB0	25	04		BCS	LOOP8
587	5AB2	86	31		LDA	##31

588	5AB4 C0	64		SUBB	##64
589	5AB6 BD	5B71	LOOP8	JSR	>OUTCX
590	5AB9 4F			CLRA	
591	5ABA 20	02		BRA	LOOP9
592					
593	5ABC B6	01	OUTDEZ	LDA	##01
594	5ABE 34	02	LOOP9	PSHS	A
595	5AC0 B6	FF		LDA	##FF
596	5AC2 4C		LOP1	INCA	
597	5AC3 C0	0A		SUBB	##0A
598	5ACS 24	FB		BCC	LOP1
599	5AC7 CB	0A		ADDB	##0A
600	5AC9 BB	30		ADDA	##30
601	5ACB B1	30		CMFA	##30
602	5ACD 26	06		BNE	OUT2
603	5ACF 6D	E4		TST	,S
604	5AD1 27	10		BEQ	OUT7
605	5AD3 B6	20		LDA	##20
606	5ADS 34	04	OUT2	PSHS	B
607	5AD7 BD	5B71		JSR	>OUTCX
608	5ADA 35	02		PULS	A
609	5ADC BB	30		ADDA	##30
610	5ADE 32	61		LEAS	#01,S
611	5AE0 7E	5B71		JMF	>OUTCX
612					
613	5AE3 B6	30	OUT7	LDA	##30
614	5AE5 20	EE		BRA	OUT2
615					
616	5AE7 34	10	SECUR	PSHS	X
617	5AE9 34	04		PSHS	B
618	5AEB C6	0A		LDB	##0A
619	5AED 3D			MUL	
620	5AEE 34	06		PSHS	B,A
621	5AF0 CC	00FE		LDD	##00FE
622	5AF3 A3	E4		SUBD	,S
623	5AF5 FD	EF07		STD	>YKDR
624	5AFB 32	62		LEAS	#02,S
625	5AFA 35	04		PULS	B
626	5AFC B6	06		LDA	##06
627	5AFE 3D			MUL	
628	5AFF FD	EF05		STD	>XKDR
629	5B02 35	90		PULS	PC,X
630					
631	5B04 34	04	SETOUT	PSHS	B
632	5B06 34	02		PSHS	A
633	5B0B A6	E4	SETOT1	LDA	,S
634	>5B0A BD	5B71		JSR	>OUTCX
635	5B0D 6A	61		DEC	#01,S
636	5B0F 26	F7		BNE	SETOT1
637	5B11 35	B6		PULS	PC,B,A
638					
639	5B13 B6	20	GFP	LDA	##20
640	>5B15 7E	5B71		JMF	>OUTCX
641					

642	5B18	34	20	TASBE	PSHS	Y
643	5B1A	CE	0010		LDU	#WAV10
644	5B1D	FF	EF05		STU	>XKOR
645	5B20	CE	0008		LDU	#WAVX8
646	5B23	FF	EF07		STU	>YKOR
647	5B26	A6	80	LOP2	LDA	,X+
648	5B28	81	FF		CMPL	##FF
649	5B2A	27	04		BEQ	LOP3
650	5B2C	8D	05		BSR	TASTX
651	5B2E	20	F6		BRA	LOP2
652						
653	5B30	32	62	LOP3	LEAS	#02,S
654	5B32	39			RTS	
655						
656	5B33	10AE	62	TASTX	LDY	#02,S
657	5B36	4A		LOP4	DECA	
658	5B37	27	04		BEQ	LOP5
659	5B39	31	28		LEAY	#08,Y
660	5B3B	20	F9		BRA	LOP4
661						
662	5B3D	C6	09	LOP5	LDB	##09
663	5B3F	5A		TASTX3	DECB	
664	5B40	27	07		BEQ	TASTX4
665	5B42	A6	A0		LDA	,Y+
666	>5B44	BD	5B71		JSR	>OUTCX
667	5B47	20	F6		BRA	TASTX3
668						
669	5B49	39		TASTX4	RTS	
670						
671	5B4A	34	04	TASHEL	PSHS	B
672	5B4C	4A			DECA	
673	5B4D	C6	08		LDB	##08
674	5B4F	F7	EA2D		STB	>MERK1
675	5B52	C6	06		LDB	##06
676	5B54	3D			MUL	
677	5B55	C3	8D42		ADDD	##8D42
678	5B58	1F	01		TFR	D,X
679	5B5A	C6	06		LDB	##06
680	5B5C	A6	84	TASH1	LDA	,X
681	5B5E	43			COMA	
682	5B5F	A7	80		STA	,X+
683	5B61	5A			DECB	
684	5B62	26	F8		BNE	TASH1
685	5B64	30	8B 3A		LEAX	#3A,X
686	5B67	C6	06		LDB	##06
687	5B69	7A	EA2D		DEC	>MERK1
688	5B6C	26	EE		BNE	TASH1
689	5B6E	35	04		PULS	B
690	5B70	39			RTS	
691						
692	5B71	BD	F018	OUTCX	JSR	>OUTCX
693	5B74	7D	EF0E		TST	>INVFL6
694	5B77	26	03		BNE	OUTC1
695	5B79	BD	5B84		JSR	>INVCH

696	5B7C 39		OUTC1	RTS	
697					
698	5B7D B6	FCF1	INCHA	LDA	>KEYBB
699	5B80 2A	10		BPL	INCH1
700	5B82 B6	FCF0		LDA	>KEYBO
701	5B85 81	06		CMPA	##06
702	5B87 26	09		BNE	INCH1
703	5B89 7F	EE04		CLR	>STOR4
704	5B8C 7F	EF0E		CLR	>INVFLG
705	5B8F 7E	CD00		JMP	>FLEX
706					
707	5B92 8D	3D	INCH1	BSR	SOFT1
708	5B94 81	14		CMPA	##14
709	5B96 27	ES		BEQ	INCHA
710	5B98 7D	EA48		TST	>ZIFF
711	5B9B 27	2B		BEQ	INCH2
712	5B9D 7D	EB05		TST	>INESC
713	5BA0 27	06		BEQ	ESCAP2
714	5BA2 4D			TSTA	
715	5BA3 26	03		BNE	ESCAP2
716	5BA5 86	FF		LDA	##FF
717	5BA7 39			RTS	
718					
719	5BA8 80	0A	ESCAP2	SUBA	##0A
720	>5BA 102B	FFCF		LBMI	INCHA
721	5BAE 4C			INCA	
722	5BAF 81	0A		CMPA	##0A
723	5BB1 26	01		BNE	INCH3
724	5BB3 4F			CLRA	
725	5BB4 7D	EA36	INCH3	TST	>ECHO
726	5BB7 27	0F		BEQ	INCH2
727	5BB9 34	02		PSHS	A
728	5BBB 7F	EF0E		CLR	>INVFLG
729	5BBE 8B	30		ADDA	##30
730	>5BC0 BD	5B71		JSR	>OUTCX
731	5BC3 7C	EF0E		INC	>INVFLG
732	5BC6 35	02		PULS	A
733	5BCB 39		INCH2	RTS	
734					
735	5BC9 BF	EB0D	SOFTKY	STX	>STOR2
736	5BCC 7F	EA49		CLR	>ALTZ
737	5BCF 35	90		PULS	PC,X
738					
739	5BD1 7D	EB0C	SOFT1	TST	>STOR1
740	5BD4 27	12		BEQ	SOFT2
741	5BD6 2A	10		BPL	SOFT2
742	5BD8 34	10		PSHS	X
743	5BDA BE	EB0D		LDX	>STOR2
744	5BDD A6	80		LDA	,X+
745	5BDF 81	FF		CMPA	##FF
746	5BE1 26	E6		BNE	SOFTKY
747	5BE3 7F	EB0C		CLR	>STOR1
748	5BE6 35	10		PULS	X
749	5BE8 34	34	SOFT2	PSHS	Y,X,B

CTRL (F)

750	5BEA	10BE	FCFA		LDY	#FIAA
751	5BEE	6F	E2	SOFT3	CLR	, -S
752	5BF0	8E	5C52		LDX	#JMPT0
753	5BF3	E6	80	SOFT4	LDB	, X+
754	5BF5	A6	80		LDA	, X+
755	5BF7	E7	A6		STB	A, Y
756	5BF9	4D			TSTA	
757	5BFA	27	04		BEQ	LOP6
758	5BFC	E6	80		LDB	, X+
759	5BFE	E7	A4		STB	, Y
760	5C00	E6	A4	LOP6	LDB	, Y
761	5C02	6C	E4	SOFT5	INC	, S
762	5C04	54			LSRB	
763	5C05	24	13		BCC	SOFT7
764	5C07	A6	E4		LDA	, S
765	5C09	A1	84		CMPA	, X
766	5C0B	26	F5		BNE	SOFT5
767	5C0D	30	01		LEAX	\$01, X
768	5C0F	6D	84		TST	, X
769	5C11	26	E0		BNE	SOFT4
770	5C13	35	02		PULS	A
771	5C15	7F	EA49		CLR	>ALTZ
772	5C18	35	84	SOFT6	PULS	PC, Y, X, B
773						
774	5C1A	35	02	SOFT7	PULS	A
775	5C1C	F6	EA49		LDB	>ALTZ
776	5C1F	26	0C		BNE	SOFT8
777	5C21	7C	EA49		INC	>ALTZ
778	5C24	8E	07D0		LDX	#WX7D0
779	5C27	30	1F	LOP7	LEAX	-\$01, X
780	5C29	26	FC		BNE	LOP7
781	5C2B	20	C1		BRA	SOFT3
782						
783	5C2D	C1	02	SOFT8	CMFB	#02
784	5C2F	26	04		BNE	SOFT9
785	5C31	86	14		LDA	#14
786	5C33	20	E3		BRA	SOFT6
787						
788	5C35	7C	EA49	SOFT9	INC	>ALTZ
789	5C38	4A			DECA	
790	5C39	7D	EB0C		TST	>STOR1
791	5C3C	27	DA		BEQ	SOFT6
792	5C3E	2B	D8		BMI	SOFT6
793	5C40	BE	EB0D		LDX	>STOR2
794	5C43	8C	EA10		CMFX	#RAMANF
795	5C46	26	03		BNE	LOP8
796	5C48	7F	EB0C		CLR	>STOR1
797	5C4B	A7	80	LOP8	STA	, X+
798	5C4D	BF	EB0D		STX	>STOR2
799	5C50	20	C6		BRA	SOFT6
800						
801	5C52	3C01		JMPT0	FDB	W3C01
802	5C54	EF04			FDB	STOR7
803	5C56	DF00			FDB	DRIVER

804	5C58 08BF		FDB	WX8BF	
805	5C5A 000C		FDB	WAVXC	
806	5C5C 7F00		FDB	TAXA2	
807	5C5E 1034		FDB	W1034	
808	5C60 01FF		FDB	WX1FF	
809	5C62 1400		FDB	W1400	
810	5C64 01 02 03 04	HTAS	FCB	#01, #02, #03, #04, #05, #06, #07, #08	
	5C68 05 06 07 08				
811	5C6C 09 0A FF		FCB	#09, #0A, #FF	
812	5C6F 20 45 53 43	TASTXX	FCC	" ESCAPE COPY NEWDISK YES "	
	5C73 41 50 45 20				
	5C77 20 20 43 4F				
	5C7B 50 59 20 20				
	5C7F 20 4E 45 57				
	5C83 44 49 53 4B				
	5C87 20 20 20 59				
	5C8B 45 53 20 20				
813	5C8F 20 20 4D 45		FCC	" MERGE GET STORE DELETE "	
	5C93 52 47 45 20				
	5C97 20 20 47 45				
	5C9B 54 20 20 20				
	5C9F 20 20 53 54				
	5CA3 4F 52 45 20				
	5CA7 20 44 45 4C				
	5CAB 45 54 45 20				
814	5CAF 20 46 49 4C		FCC	" FILES HELP "	
	5CB3 45 53 20 20				
	5CB7 20 20 4B 45				
	5CBB 4C 50 20 20				
815	5CBF 4B 45 4C 50	HTXTX	FCC	"HELP-PAGE"	
	5CC3 2D 50 41 47				
	5CC7 45				
816	5CC8 0D		FCB	#0D	
817	5CC9 0A		FCB	#0A	
818	5CCA 04		FCB	#04	
819	5CCB 42 55 53 2D	BUSER	FCC	"BUS-ERR"	
	5CCF 45 52 52				
820	5CD2 04		FCB	#04	
821	5CD3 4E 4F 20 4C	ERLIN	FCC	"ND LINE"	
	5CD7 49 4E 45				
822	5CDA 04		FCB	#04	
823	5CDB 5D21	HLPJMP	FDB	ESCAPE	
824	5CDD 5D45		FDB	GET	
825	5CDF 5D45		FDB	GET	
826	5CE1 5D7E		FDB	TEXAA = RTS	
827	5CE3 5D45		FDB	GET	
828	5CE5 5D45		FDB	GET	
829	5CE7 5D45		FDB	GET	
830	5CE9 5D45		FDB	GET	
831	5CEB 5D45		FDB	GET	
832	5CED 5D45		FDB	GET	
833	5CEF 7F EB04	KEYOUT	CLR	>INPENB	
834	5CF2 B6 EA3D		LDA	>PAGEM	
835	5CF5 B7 EC85		STA	>MCHECK	

836	5CF8	B6	FF		LDA	##FF
837	5CFA	B7	EA3D		STA	>PAGEM
838	5CFD	B6	0C		LDA	##0C
839	5CFF	BD	5B71		JSR	>OUTCX
840	5D02	BE	5CBF		LDX	##HTTX
841	5D05	BD	F027		JSR	>PDAT1
842	5D08	BE	5C64		LDX	##HTAS
843	5D0B	10BE	5C6F		LDY	##TASTXX
844	5D0F	BD	5B18		JSR	>TASBE
845	5D12	B6	01		LDA	##01
846	5D14	5F			CLRB	
847	5D15	BD	5AE7		JSR	>SECUR
848	5D18	7F	EA36		CLR	>ECHO
849	5D18	7C	EB05		INC	>INESC
850	5D1E	7E	5B7A		JMP	>INITAS
851						
852	5D21	B6	EC85	ESCAPE	LDA	>MCHECK
853	5D24	7D	EB00		TST	>FILE
854	5D27	27	02		BEQ	ESCA1
855	5D29	80	04		SUBA	##04
856	5D2B	B7	EA3D	ESCA1	STA	>PAGEM
857	5D2E	1F	B9		TFR	A,B
858	5D30	5A			DECB	
859	5D31	58			ASLB	
860	5D32	8E	5B00		LDX	##WASS1
861	5D35	7D	EB00		TST	>FILE
862	5D38	27	03		BEQ	LOP9
863	5D3A	8E	EB10		LDX	##STOR3
864	5D3D	7F	EA36	LOP9	CLR	>ECHO
865	5D40	7F	EB05		CLR	>INESC
866	5D43	6E	95		JMP	[B,X]
867						
868	5D45	8E	5D50	GET	LDX	##JMPT2
869	5D48	AE	B6		LDX	A,X
870	5D4A	BD	5900	STORE	JSR	>INBUF
871	5D4D	7E	5B69		JMP	>DOS
872						
873	5D50	5D64		JMPT2	FDB	FILX
874	5D52	5D68			FDB	COPX
875	5D54	5D77			FDB	NEWX
876	5D56	5D64			FDB	FILX
877	5D58	5D74			FDB	MERSX
878	5D5A	5D6E			FDB	GOTX
879	5D5C	5D71			FDB	STORX
880	5D5E	5D68			FDB	DELX
881	5D60	5D64			FDB	FILX
882	5D62	5D7A			FDB	HLPX
883						
884	5D64	46 49 20		FILX	FCC	"F1 "
885	5D67	04			FCB	##04
886						
887	5D68	43 4F		COPX	FCC	"C0"
888	5D6A	04			FCB	##04
889						

890	5D6B 44 44	DELX	FCC	"DD"
891	5D6D 04		FCB	#04
892				
893	5D6E 47 47	GOTX	FCC	"GG"
894	5D70 04		FCB	#04
895				
896	5D71 53 53	STORX	FCC	"SS"
897	5D73 04		FCB	#04
898				
899	5D74 4D 4D	MERGX	FCC	"MM"
900	5D76 04		FCB	#04
901				
902	5D77 4E 4E	NEWX	FCC	"NN"
903	5D79 04		FCB	#04
904				
905	5D7A 4B	HLPX	FCC	"H"
906	5D7B 04		FCB	#04
907				
908	5D7C 44	DCMDX	FCC	"D"
909	5D7D 04		FCB	#04
910				
911				
912	5D7E 39	TEXAA	RTS	
913				
914	5D7F 7F EA36	CLR	>ECHO	
915	5D82 BD 5B7D	JSR	>INCHA	
916	5D85 B1 04	CMFA	#*04	
917	5D87 25 03	BCS	LOLO	
918	5D89 1C FE	ANDCC	#*FE	
919	5D8B 39	RTS		
920				
921	5D8C 1A 01	LOLO	ORCC	#*01
922	5D8E 39		RTS	
923				
924	5D8F FD E900	TEXAB	STD	>ZE900
925	5D92 A6 9B 02		LDA	[*02,X]
926	5D95 B7 EA3E		STA	>UNIT
927	5D9B EC B4		LDD	,X
928	5D9A 20 4A		BRA	SENDE
929				
930	5D9C 7F EA62	SENTST	CLR	>SENDF
931	5D9F 7D FD01		TST	>PIA+1
932	5DA2 2A 34		BFL	SEND2
933	5DA4 B6 FE		LDA	#*FE
934	5DA6 B7 FD02		STA	>PIA+2
935	5DA9 7F FD01		CLR	>PIA+1
936	5DAC B6 FF		LDA	#*FF
937	5DAE B7 FD00		STA	>PIA
938	5DB1 C6 04		LDB	#*04
939	5DB3 F7 FD01		STB	>PIA+1
940	5DB6 B7 FD00		STA	>PIA
941	5DB9 B6 FD00		LDA	>PIA
942	5DBC 5F		CLRB	
943	5DBD 46	SEND1	RORA	

x Mittel

code

944	5DBE 24	19	BCC	SEND3
945	5DC0 5C		INCB	
946	5DC1 C1	08	CMFB	##08
947	5DC3 26	F8	BNE	SEND1
948	5DC5 B6	FD00	LDA	>PIA
949	5DC8 7F	FD01	CLR	>PIA+1
950	5DCB 7F	FD00	CLR	>PIA
951	5DCE 86	04	LDA	##04
952	5DD0 87	FD01	STA	>PIA+1
953	5DD3 86	FF	LDA	##FF
954	5DD5 B7	FD02	STA	>PIA+2
955	5DD8 39		SEND2	RTS
956				
957	5DD9 58		SEND3	ASLB
958	5DDA 58			ASLB
959	5DDB 58			ASLB
960	5DDC 58			ASLB
961	5DD0 F7	EA3E	STB	>UNIT
962	5DE0 7C	EA62	INC	>SENDF
963	5DE3 FC	EA64	LDD	>FUNKT
964	5DE6 34	02	PSHS	A
965	5DE8 B6	EA3E	LDA	>UNIT
966	5DEB 81	FF	CMFA	##FF
967	5DED 1027	0107	LBEQ	ERSEND
968	5DF1 35	02	PULS	A
969	5DF3 7F	EA4A	CLR	>TSWAVE
970	5DF6 84	0F	ANDA	##0F
971	5DF8 34	02	PSHS	A
972	5DFA 34	04	PSHS	B
973	5DFC B4	07	ANDA	##07
974	5DFE 81	03	CMFA	##03
975	5E00 23	4A	SLS	SEND7
976	5E02 81	05	CMFA	##05
977	5E04 27	39	BEQ	SEND6
978	5E06 1083	0701	CMPD	##0701
979	5E0A 27	2B	BEQ	SEND5
980	5E0C 1083	0700	CMPD	##0700
981	5E10 27	0A	BEQ	SNND2
982	5E12 32	62	LEAS	*02,5
983	5E14 39		RTS	
984				
985	5E15 7C	EA4A	SNND1	INC >TSWAVE
986	5E18 32	62	LEAS	*02,5
987	5E1A 20	A9	BRA	SEN11
988				
989	5E1C 8E	0000	SNND2	LDX ##WAVBAS
990	5E1F B6	EA3E	LDA	>UNIT
991	5E22 27	07	BEQ	SNND3
992	5E24 81	20	CMFA	##20
993	5E26 27	0A	BEQ	SNND4
994	5E28 8E	1000	LDX	##W1000
995	5E2B 1F	10	SNND3	TFR X,D
996	5E2D C3	0800	ADDD	##0800
997	5E30 20	26	BRA	SEND8

Re-init Pias

Wave 2.3
INFO Data
Transfer
Routine

AB Code (0700)

998					
999	5E32	8E	0800	SNND4	LDX #WXB00
1000	5E35	20	F4		BRA SNND3
1001					
1002	5E37	8E	EC81	SENDS	LDX >ANFA
1003	5E3A	FC	EC83		LDD >ENDE
1004	5E3D	20	19		BRA SEND8
1005					
1006	5E3F	8E	5FE6	SEND5	LDX #CON61
1007	5E42	58			ASLB
1008	5E43	58			ASLB
1009	5E44	30	85		LEAX B,X
1010	5E46	EC	02		LDD #02,X
1011	5E48	AE	84		LDX ,X
1012	5E4A	20	0C		BRA SEND8
1013					
1014	5E4C	8E	5FE2	SEND7	LDX #CONST
1015	5E4F	E6	86		LDB A,X
1016	5E51	4F			CLRA
1017	5E52	8E	E900		LDX #ZE900
1018	5E55	C3	E900		ADDD ##E900
1019	5E58	FD	EC83	SEND8	STD >ENDE
1020	5E5B	BF	EC81		STX >ANFA
1021	5E5E	B3	EC81		SUBD >ANFA
1022	5E61	FD	EC89		STD >MBLOCK
1023	5E64	B6	FD00		LDA >PIA
1024	5E67	B6	FE		LDA ##FE
1025	5E69	B7	FD02		STA >PIA+2
1026	5E6C	B6	FD01		LDA >PIA+1
1027	5E6F	2B	A4		BMI SNND1
1028	5E71	7F	FD01		CLR >PIA+1
1029	5E74	B6	FF		LDA ##FF
1030	5E76	B7	FD00		STA >PIA
1031	5E79	C6	04		LDB ##04
1032	5E7B	F7	FD01		STB >PIA+1
1033	5E7E	B6	FD00		LDA >PIA
1034	5E81	35	04		PULS B
1035	5E83	F7	FD00		STB >PIA
1036	5E86	7F	EC8C		CLR >ERFLB
1037	5E89	A6	E4		LDA ,S
1038	5E8B	BA	EA3E		ORA >UNIT
1039	5E8E	B7	FD02		STA >PIA+2
1040	5E91	8E	4000		LDX #TENDE
1041	5E94	30	1F	SEND9	LEAX -#01,X
1042	>SE96	1027	005E		LBEQ ERSEND
1043	5E9A	7D	FD01		TST >PIA+1
1044	5E9D	2A	F5		ROL SEND9
1045	5E9F	B6	FE		LDA ##FE
1046	5EA1	B7	FD02		STA >PIA+2
1047	5EA4	A6	E4		LDA ,S
1048	5EA6	B5	08		BITA ##08
1049	5EAB	1026	00B0		LDNE EMPE8
1050	5EAC	C6	3C		LDB ##3C
1051	5EAE	F7	FD01		STB >PIA+1

A Code = ~~7~~, B Code = 1 (07-01)

A Code = 5

A Code <= 3

Block gröszen INFD

BLOCKLÄNGE

----- Error! : Rinit

B Code Transfer

A Code "

Wait Loop

Receive Data Mode?

```

1052 5EB1 B6 ECB9 LDA >MBLOCK
1053 5EB4 B0 5F39 JSR >EMPF5
1054 5EB7 B6 EC8A LDA >LBLOCK
1055 5EBA B0 7D BSR EMPF5
1056 5EB8 7F EC86 CLR >LCHECK
1057 5EBF BE ECB1 LDX >ANFA
1058 5EC2 A6 80 SENDA LDA ,X+
1059 5EC4 B0 73 BSR EMPF5
1060 5EC6 BC EC83 CMPX >ENDE
1061 5EC9 26 F7 BNE SENDA
1062 5ECB B6 EC86 LDA >LCHECK
1063 5ECE B0 69 BSR EMPF5
1064 5ED0 C6 64 LDB ##64
1065 5ED2 5A SENDB DECB
1066 5ED3 26 FD BNE SENDB
1067 5ED5 7F EA4A CLR >TSWAVE
1068 5ED8 32 61 SENDC LEAS #01,S
1069 5EDA 7F FD01 CLR >PIA+1
1070 5EDD 7F FD00 CLR >PIA
1071 5EE0 B6 04 LDA ##04
1072 5EE2 B7 FD01 STA >PIA+1
1073 5EE5 B6 FF LDA ##FF
1074 5EE7 7D EA6E TST >HMERK
1075 5EEA 27 02 BEQ SENC
1076 5EEC B6 FE LDA ##FE
1077 5EEE B7 FD02 SENC STA >PIA+2
1078 5EF1 B6 FD00 LDA >PIA
1079 5EF4 7F EA6E CLR >HMERK
1080 5EF7 39 RTS

```

```

1081
1082 5EF8 FC EA6F ERSEND LDD >LMERK
1083 5EFB BD 5AE7 JSR >SECUR
1084 5EFE BE 5CD3 LDX #ERLIN
1085 5F01 BD F027 JSR >PDAT1
1086 5F04 7C EA4A INC >TSWAVE
1087 5F07 20 CF BRA SENDC

```

```

1088
1089 5F09 6D 62 EMFF TST #02,S
1090 5F0B 27 14 BEQ EMFF2
1091 5F0D 7D EC8C TST >ERFLG
1092 5F10 26 07 BNE EMFF1
1093 5F12 10BE 0014 LDY #WAV14
1094 5F16 7C EC8C INC >ERFLG
1095 5F19 31 3F EMFF1 LEAY -#01,Y
1096 5F1B 10BC 0000 CMPY #WAVBAS
1097 5F1F 26 18 BNE EMFF5
1098 5F21 32 62 EMFF2 LEAS #02,S
1099 5F23 20 D3 BRA ERSEND

```

```

1100
1101 5F25 CE E000 EMFF3 LDU #ZE000
1102 5F28 33 5F EMFF4 LEAU -#01,U
1103 5F2A 11G3 0000 CMPL #WAVBAS
1104 >5F2E 1027 FFD7 LBED EMFF
1105 5F32 7D FD01 TST >PIA+1

```

No Line!

bei 20 Versuchen ERFLG = 1!

Wait

1106	5F35 2A	F1	BPL	EMPF4
1107	5F37 20	09	BRA	EMPF7
1108				
1109	5F39 5F		EMPF5	CLRB
1110	5F3A 5A		EMPF6	DECB
1111	5F3B 27	E8	BEQ	EMPF3
1112	5F3D 7D	FD01	TST	>PIA+1
1113	5F40 2A	F8	BPL	EMPF4
1114	5F42 F6	FD00	EMPF7	LDB >PIA
1115	5F45 B7	FD00	STA	>PIA
1116	5F48 BB	EC86	ADDA	>LCHECK
1117	5F4B C6	34	LDB	##34
1118	5F4D F7	FD01	STB	>PIA+1
1119	5F50 C6	3C	LDB	##3C
1120	5F52 F7	FD01	STB	>PIA+1
1121	5F55 B7	EC86	STA	>LCHECK
1122	5F58 7F	ECBC	CLR	>ERFLG
1123	5F5B 39		RTS	
1124				
1125	5F5C 7F	FD01	EMPF8	CLR >PIA+1
1126	5F5F 7F	FD00	CLR	>PIA
1127	5F62 86	24	LDA	##24
1128	5F64 87	FD01	STA	>PIA+1
1129	5F67 7F	EC86	CLR	>LCHECK
1130	5F6A B6	FD00	LDA	>PIA
1131	5F6D B7	EC83	STA	>ENDE
1132	5F70 8D	34	BSR	EMPFA
1133	5F72 B7	EC84	STA	>ENDE1
1134	5F75 FC	EC83	LDD	>ENDE
1135	5F78 10B3	4100	CMPD	##4100
1136	5F7C 24	38	BCC	EREMFF
1137	5F7E BE	EC81	LDX	>ANFA
1138	5F81 FC	EC81	LDD	>ANFA
1139	5F84 F3	EC83	ADDD	>ENDE
1140	5F87 FD	EC83	STD	>ENDE
1141	5F8A 8D	1A	EMPF9	BSR EMPFA
1142	5F8C A7	80	STA	,X+
1143	5F8E BB	EC86	ADDA	>LCHECK
1144	5F91 B7	EC86	STA	>LCHECK
1145	5F94 BC	EC83	CMPL	>ENDE
1146	5F97 26	F1	BNE	EMPF9
1147	5F99 8D	0B	BSR	EMPFA
1148	5F9B B1	EC86	CMPL	>LCHECK
1149	5F9E 26	16	BNE	EREMFF
1150	5FA0 7F	EA4A	CLR	>TSWAVE
1151	5FA3 16	FF32	LBRA	SEND
1152				
1153	5FA6 5F		EMPFA	CLRB
1154	5FA7 5A		EMPFB	DECB
1155	5FAB 27	34	BEQ	EMPFE
1156	5FAA 7D	FD01	TST	>PIA+1
1157	5FAD 2A	F8	BPL	EMPFB
1158	>5FAF 8D	5FB5	JBR	>EMPFC
1159	5FB2 B6	FD00	LDA	>PIA

Transmit Byte
wait

Receive Data

Buss Error!

1160	5FB5 39		EMPFC	RTS	
1161					
1162	5FB6 FC	EA6F	EREMPF	LDD	>LMERK
1163	5FB9 8D	5AE7		JSR	>SECUR
1164	5FBC 8E	5CCB		LDX	#BUSER
1165	5FBF 8D	F027		JSR	>PDAT1
1166	5FC2 7C	EA4A		INC	>TSWAVE
1167	5FC5 16	FF10		LBRA	SENDC
1168					
1169	5FCB C6	FF		LDB	##FF
1170	5FCA 5A		EMPPD	DECB	
1171	5FCB 27	11		BEQ	EMPFE
1172	5FCD 7D	FD01		TST	>PIA+1
1173	5FD0 2A	F8		BPL	EMPPD
1174	5FD2 B6	FD00		LDA	>PIA
1175	5FD5 A7	80		STA	,X+
1176	5FD7 B8	EC86		ADDA	>LCHECK
1177	5FDA B7	EC86		STA	>LCHECK
1178	5FDD 39			RTS	
1179					
1180	5FDE 32	62	EMPFE	LEAS	#02,S
1181	5FE0 20	D4		BRA	EREMPF
1182					
1183	5FE2 01 02 10 64	CONST	FCB		#01,#02,#10,#64
1184					
1185	5FE6 0000	CONS1	FDB		WAVBAS
1186	5FE8 2C00		FDB		W2C00
1187	5FEA 0000		FDB		WAVBAS
1188	5FEC 1400		FDB		W1400
1189	5FEE 4000		FDB		TENDE
1190	5FF0 5800		FDB		WASS1
1191	5FF2 0000		FDB		WAVBAS
1192	5FF4 3000		FDB		W3000
1193	5FF6 0000		FDB		WAVBAS
1194	5FF8 4000		FDB		TENDE
1195					
1196			END		START

0 ERROR(S) DETECTED

SYMBOL TABLE:

ALTZ	EA49	AMPL	EA3B	ANFA	ECB1	BANK	EA6B	BITPTR	EA26
BUSER	5CCB	BYTEZ	EA27	CLMERK	EA45	CONS1	5FE6	CONST	5FE2
COFX	5D6B	DCMDX	5D7C	DELET	595E	DELTA	EA2F	DELX	5D6B
DOCMND	CD4B	DOS	5BE9	DOS1	5BFD	DOSER	CC20	DRIVER	DF00
ECHO	EA36	ENGAB	5913	EMPF	5F09	EMPF1	5F19	EMPF2	5F21
EMPF3	5F25	EMPF4	5F2B	EMPF5	5F39	EMPF6	5F3A	EMPF7	5F42
EMPF8	5F5C	EMPF9	5F8A	EMPFA	5FA6	EMPFB	5FA7	EMPFC	5FB5
EMPFD	5FCA	EMPFE	5FDE	ENDE	ECB3	ENDE1	ECB4	EREMPF	5FB6
ERFLB	ECBC	ERLIN	5CD3	ERSEND	5EF8	ESCA1	5D2B	ESCAP2	5BA8
ESCAPE	5D21	EVUA	EA6C	FAKTOR	EA5B	FILE	EB00	FILX	5D64
FLEX	CD00	FMSCLS	D403	FUNDAM	EA3C	FUNKT	EA64	GET	5D45
GETEX	598C	GETRX	59A0	GETTCH	5B6A	GETX	5D6E	HALFTE	EA46
HARMN	EA2C	HLPJMP	5CDB	HLPX	5D7A	HMERK	EA6E	HOLFIL	597D
HTAS	5C64	HTXTX	5CBF	INB1	5912	INB2	5908	INBUF	5900
INCH1	5B92	INCH2	5BCB	INCH3	5BB4	INCHA	5B7D	IND2	5AB2
IND3	5A9F	IND4	5A66	IND6	5A6D	IND9	5AA2	INDE2	59E3
INDE3	59F1	INDE4	59F5	INDE6	5A01	INDE9	5A3A	INDEZ0	5A43
INDZC	59C4	INESC	EB05	ININE1	596A	ININEU	5957	INITAS	5B7A
INFENB	EB04	INPOS	59B1	INPOS1	59B0	INPU	EB02	INFW	EB01
INTAS1	5BB0	INTAS2	5BB6	INTAS3	5BCC	INTAS4	5BD3	INTG	EA3C
INVCH	598A	INVER1	59CF	INVER5	5A14	INVFLB	EF0E	INVSr	FF05
JMPT0	5C52	JMPT2	5D50	JMPTAB	5B10	KEY	EA51	KEYBB	FCF1
KEYBM	EA6A	KEYBO	FCF0	KEYOUT	5CEF	LBLOCK	ECBA	LBUFR	C0B0
LCHECK	EC86	LMERK	EA6F	LOLO	5D8C	LOOP	EA53	LOOP1	5B5D
LOOP2	5B80	LOOP3	5BDF	LOOP4	59FB	LOOP5	5A12	LOOP6	5A3D
LOOP7	5A70	LOOP8	5AB6	LOOP9	5ABE	LOOPA	EA54	LOOPL	EA56
LDP1	5AC2	LDP2	5B26	LDP3	5B30	LDP4	5B36	LDP5	5B3D
LDP6	5C00	LDP7	5C27	LDP8	5C4B	LDP9	5D3D	LOPANF	EA58
LDPKL	EA5A	LPTR	CC14	MBLOCK	ECB9	MCHECK	ECB5	MEM00	EA70
MEM01	EA71	MEM02	EA72	MEM03	EA73	MEM04	EA74	MERGX	5D74
MERK1	EA2D	MERK2	EA2E	MERK3	EA39	MERK4	EA3A	MINUS	EA31
NATANF	EA41	NEUINI	5921	NEWX	5D77	NULAGE	EA29	QUD2	5AD5
QUD7	5AE3	QUTC1	5B7C	QUTCX	F018	QUTCX	5B71	QUTDEZ	5ABC
QUTHUN	5AAC	PAGEM	EA3D	PDATA1	F027	PEBEL	EA2A	PERZ	EA43
PFLB	EA66	PHI	EA61	PIA	FD00	PIAA	FCFA	PUNKT2	EA44
PWN	EA3B	RAMANF	EA10	RECCC	EA67	RESULT	EA5F	SDELTA	EA30
SECUR	5AE7	SEN11	5DC5	SENCC	5EEE	SEND1	5DBD	SEND2	5DD8
SEND3	5DD9	SEND5	5E37	SEND6	5E3F	SEND7	5E4C	SEND8	5E58
SEND9	5E74	SENDA	5EC2	SEND8	5ED2	SENDC	5ED8	SENDE	5DE6
SENDF	EA62	SENTST	5D9C	SETOT1	5B0B	SETOUT	5B04	SNND1	5E15
SNND2	5E1C	SNND3	5E2B	SNND4	5E32	SOFKEY	EE05	SOFT1	5BD1
SOFT2	5BE8	SOFT3	5BEE	SOFT4	5BF3	SOFT5	5C02	SOFT6	5C18
SOFT7	5C1A	SOFT8	5C2D	SOFT9	5C35	SOFTKY	5BC9	SPLIT	EA69
SPP	5B13	START	5B3E	STOR1	EB0C	STOR2	EB0D	STOR3	EB10
STOR4	EE04	STOR5	EE09	STOR6	EF00	STOR7	EF04	STORE	5D4A
STORX	5D71	TASBE	5B1B	TASH1	5B5C	TASHEL	5B4A	TASTX	5B33
TASTX3	5B3F	TASTX4	5B49	TASTXX	5C6F	TAXA1	6003	TAXA2	7F00
TENDE	4000	TESTM	EA6B	TEXAA	5D7E	TEXAB	5D8F	TSWAVE	EA4A
UNIT	EA3E	VERSAZ	5944	VERSIO	EA3F	VLAGE	EA32	W1000	1000
W1034	1034	W1400	1400	W2C00	2C00	W3000	3000	W3C01	3C01

LOOP7	00555	00557		
LOOP8	00589	00586		
LOOP9	00594	00571		
LOOPA	00156			
LOOPL	00158			
LOP1	00596	00598		
LOP2	00647	00651		
LOP3	00653	00649		
LOP4	00657	00660		
LOP5	00662	00658		
LOP6	00760	00757		
LOP7	00779	00780		
LOP8	00797	00795		
LOP9	00864	00862		
LOPANF	00160			
LOPKL	00162			
LPTER	00029	00386		
MBLOCK	00257	01022	01052	
MCHECK	00255	00835	00852	
MEM00	00195			
MEM01	00196			
MEM02	00197			
MEM03	00198			
MEM04	00199			
MERGX	00899	00877		
MERK1	00088	00674	00687	
MERK2	00090			
MERK3	00108			
MERK4	00110			
MINUS	00096			
NATANF	00124			
NEUINI	00403	00400	00430	00435
NEWX	00902	00875		
NULAGE	00080			
QUD2	00606	00602	00614	
QUD7	00613	00604		
QUTC1	00696	00694		
QUTCH	00049	00692		
QUTCX	00692	00282	00524	00526 00544 00572 00589 00607 00611 00634 00640
	00666	00730	00839	
QUTDEZ	00593	00271	00529	
QUTHUN	00584	00272		
PAGEM	00116	00334	00353	00418 00434 00834 00837 00856
FDATA1	00050	00841	01085	01165
PEGEL	00082			
PERZ	00126			
PFLG	00178			
PHI	00170			
PIA	00054	00931	00934	00935 00937 00939 00940 00941 00948 00949 00950
	00952	00954	01023	01025 01026 01028 01030 01032 01033 01035 01039
	01043	01046	01051	01069 01070 01072 01077 01078 01105 01112 01114
	01115	01118	01120	01125 01126 01128 01130 01156 01159 01172 01174
PIAA	00053	00750		
PUNKTZ	00128			
PWN	00106			
RAMANF	00068	00794		
RECCC	00180			
RESULT	00168			
SDELTA	00094			
SECUR	00616	00275	00462	00516 00847 01083 01163
SEN11	00948	00987		
SENCC	01077	01075		
SEND1	00943	00947		
SEND2	00955	00932		
SEND3	00957	00944		

SEND5	01002 00979
SEND6	01006 00977
SEND7	01014 00975
SEND8	01019 00997 01004 01012
SEND9	01041 01044
SENDA	01058 01061
SENDB	01065 01066
SEND C	01068 01087 01151 01167
SENDE	00964 00283 00928
SEND F	00172 00930 00962
SENTST	00930 00287
SETQT1	00633 00636
SETOUT	00631 00274
SNND1	00985 01027
SNND2	00989 00981
SNND3	00995 00991 01000
SNND4	00999 00993
SDFKEY	00042 00294
SOFT1	00739 00293 00707
SOFT2	00749 00740 00741
SOFT3	00751 00781
SOFT4	00753 00769
SOFT5	00761 00766
SOFT6	00772 00786 00791 00792 00799
SOFT7	00774 00763
SOFT8	00783 00776
SOFT9	00788 00784
SDFTKY	00735 00746
SPLIT	00184
SPP	00639 00467
START	00291 00404 01196
STDR1	00244 00300 00739 00747 00790 00796
STDR2	00245 00735 00743 00793 00798
STDR3	00039 00863
STDR4	00041 00292 00703
STDR5	00043 00295 00299
STDR6	00044 00319
STDR7	00045 00802
STORE	00870 00307 00309 00433 00447 00813
STORX	00896 00879
TABBE	00642 00266 00844
TASH1	00680 00684 00688
TASHEL	00671 00278 00329 00360
TASTX	00656 00650
TASTX3	00663 00667
TASTX4	00669 00664
TASTXX	00812 00843
TAXA1	00026 00415
TAXA2	00027 00806
TENDE	00022 00304 01040 01189 01194
TEBTH	00182
TEXAA	00912 00826
TEXAB	00924 00277
TSWAVE	00140 00969 00985 01067 01086 01150 01166
UNIT	00118 00926 00961 00965 00990 01038
VERSAZ	00418 00411 00439 00444
VERSID	00120
VLAGB	00098
W1000	00016 00994
W1034	00017 00807
W1400	00018 00809 01188
W2C00	00019 01186
W3000	00020 01192
W3C01	00021 00801
WALEND	00074

WASS1	00023 00419 00860 01190
WASS2	00024 00339
WAV10	00010 00643
WAV14	00011 01093
WAVBAS	00007 00301 00423 00989 01096 01103 01185 01187 01191 01193
WAVN	00152
WAVNU	00174
WAVXB	00008 00645
WAVXC	00009 00805
WELANF	00070
WELEND	00072
WERT	00104
WTABL	00134
WX1FF	00012 00808
WX7D0	00013 00778
WXB00	00014 00999
WXBBF	00015 00804
XGETX	00313 00306
XKDR	00046 00628 00644
XKDRME	00100
XPOA	00146
XPOS	00142
XTCMD	00316 00308
YKDR	00047 00623 00646
YPOA	00148
YPOS	00144
ZE000	00035 01101
ZE900	00036 00924 01017
ZEHNER	00084
ZIFF	00136 00323 00534 00579 00710
ZOOMER	00122

6.10.84

VCM D A

V2 R3.3

Wave term

ALTZ	00138 00736 00771 00775 00777 00788
AMPLL	00112
ANFA	00252 01002 01020 01021 01057 01137 01138
BANK	00188
BITPTR	00076
BUSER	00819 01164
BYTEZ	00078
CLMERK	00130
CONS1	01185 01006
CONST	01183 01014
CDPX	00887 00874
DCMDX	00908 00432
DELET	00432 00406
DELTA	00092
DELX	00890 00880
DOCMND	00032 00375
DOS	00373 00286 00871
DOS1	00382 00377
DOSER	00030 00380
DRIVER	00034 00803
ECHO	00102 00322 00471 00473 00541 00569 00580 00725 00846 00864 00914
EINGAB	00395 00279
EMFF	01089 01104
EMPF1	01095 01092
EMPF2	01098 01090
EMPF3	01101 01111
EMPF4	01102 01106
EMPF5	01109 01053 01055 01059 01063 01097
EMPF6	01110 01113
EMPF7	01114 01107
EMPF8	01125 01049
EMPF9	01141 01146
EMPFA	01153 01132 01141 01147
EMFFB	01154 01157
EMPFC	01160 01158
EMPFD	01170 01173
EMFFE	01180 01155 01171
ENDE	00253 01003 01019 01060 01131 01134 01139 01140 01145
ENDE1	00254 01133
EREMPF	01162 01136 01149 01181
ERFLB	00259 01036 01091 01094 01122
ERLIN	00821 01084
ERSEND	01082 00967 01042 01099
ESCA1	00856 00854
ESCAP2	00719 00713 00715
ESCAPE	00852 00812 00823
EVUA	00190
FAKTOR	00164
FILE	00239 00410 00417 00438 00443 00853 00861
FILX	00884 00873 00876 00881
FLEX	00031 00705
FMSCLS	00033 00379
FUNDAM	00114
FUNKT	00176 00963
GET	00868 00313 00455 00458 00813 00824 00825 00827 00828 00829 00830
	00831 00832
GETEX	00455 00440
GETRX	00458 00412
GETTCMD	00308 00297
GOTX	00893 00878
HALFTE	00132
HARPM	00086
HLPJMP	00823 00333

